

Important information - assembly of eyes.

1. It is crucial to mount the stopper close to the back of the eye - at the base of the stem.
2. Strengthen the grip of the stopper on the eye/stem by melting the end part of the stem.
3. Watch our video demonstrating how to melt the end of the stem slightly and then press it wide.
4. This way, the end becomes wider than the hole in the stopper, significantly enhancing the assembly's strength.
5. **Always** remember to check that the eye and stopper are intact, and that the assembly is securely fastened to the needlework.

[https://www.youtube.com/watch?v= ZQv_flfyfg](https://www.youtube.com/watch?v=ZQv_flfyfg)

